


Technical News Bulletin

Steinhausen, January 2025



Modular Air Supply Piping

- Enhanced flexibility Modular concept
- Easier future upgrades



Introduction

The improved air supply piping for IS/AIS machines adopts a modular approach, offering a flexible solution to meet customer requirements while allowing for future modifications to the air supply line for each function.


In recent years, numerous requests for customized air supply design for IS and AIS machines required significant engineering and manufacturing efforts.

With the introduction of the Modular Air Supply Piping, Bucher Emhart Glass presents a solution that can accommodate customer needs, by selecting specific "modules" for the air supply line.

Specification

The specification is made from a single configuration drawing (200-2330-1), including 11 sub-assemblies. The selection process is then guided by the following features:

- Function to be fed
- Regulator / Filter / Filter + Regulator
- Supply side (Left Hand (LH) / Right Hand (RH) / Both)





| Function | Cold Side | Supply Side | Regulator | Filter | Part number |
|-------------------|-----------|-----------------|-----------|--------|-------------|
| LH | | LH | Х | - | 200-2331-1 |
| | | * LH +RH | Х | - | 200-2331-2 |
| | | LH | - | Х | 200-2331-3 |
| | LH | LH+RH | - | Х | 200-2331-4 |
| | | LH | Х | Х | 200-2331-5 |
| | | * LH +RH | Х | Х | 200-2331-6 |
| Final Blow | | RH | Х | - | 200-2331-7 |
| | | * RH +LH | Х | - | 200-2331-8 |
| | DU | RH | - | Х | 200-2331-9 |
| | RH | RH+LH | - | Х | 200-2331-4 |
| | | RH | Х | Х | 200-2331-10 |
| | | * RH +LH | Х | Х | 200-2331-11 |
| | | LH | Х | - | 200-2332-1 |
| | | * LH +RH | Х | - | 200-2332-2 |
| | | LH | - | Х | 200-2332-3 |
| | LH | LH+RH | - | Х | 200-2332-4 |
| | | LH | Х | Х | 200-2332-5 |
| | | * LH +RH | Х | Х | 200-2332-6 |
| Settle Blow | | RH | Х | - | 200-2332-7 |
| | | *RH+LH | Х | - | 200-2332-8 |
| | | RH | - | Х | 200-2332-9 |
| | RH | RH+LH | - | Х | 200-2332-4 |
| | | RH | Х | Х | 200-2332-10 |
| | | *RH+LH | Х | Х | 200-2332-11 |
| | LH | LH | Х | - | 200-2333-1 |
| | | * LH +RH | Х | - | 200-2333-2 |
| | | LH | - | Х | 200-2333-3 |
| Finish Cooling | | LH+RH | - | Х | 200-2333-4 |
| | | LH | Х | Х | 200-2333-5 |
| | | * LH +RH | Х | Х | 200-2333-6 |
| | RH | RH | Х | - | 200-2333-7 |
| | | * RH +LH | Х | - | 200-2333-8 |
| | | RH | - | Х | 200-2333-9 |
| | | RH+LH | - | Х | 200-2333-4 |
| | | RH | Х | Х | 200-2333-10 |
| | | *RH+LH | Х | Х | 200-2333-11 |

• Overhead (OH) functions (Final Blow, Settle Blow, Finish Cooling) supply

* \rightarrow Master regulator side in Bold



• Overhead beam supply:

| Function | Supply Side | Part number | | |
|---|-------------|-------------|--|--|
| Air, Lubrication Oil & Water | LH | 200-2334-1 | | |
| Supply to Beam | RH | 200-2334-2 | | |
| NOTE : If not differently requested, the standard location for the air supply piping is located at the cold side | | | | |
| of the machine (furnace side). | | | | |

• Extra overhead function supply:

| Function | Supply Side | Built-in Pilot | MCU Pilot | Part number |
|-----------------------------------|-------------|----------------|-----------|-------------|
| Extra overhead function supply | | Х | - | 200-2335-1 |
| | LH | - | Х | 200-2335-2 |
| | RH | Х | - | 200-2335-3 |
| | | - | Х | 200-2335-4 |

• Blank Close and High Pressure (HP) supply:

| Function | Supply Side | Blank close | High Pressure | Part number |
|---------------|-------------|-------------|---------------|-------------|
| | LH and RH | Х | - | 200-2242-1 |
| | LH or RH | Х | - | 200-2242-2 |
| Blank Close & | LH and RH | Х | Х | 200-2242-3 |
| HP supply | LH or RH | Х | Х | 200-2242-4 |
| | LH and RH | - | Х | 200-2242-5 |
| | LH or RH | - | Х | 200-2242-6 |

• Conveyor Air supply:

| Function | Supply Side | Pocket Air | Guide Air | Pilot Air for Pocket Air, Guide Air & Dead plate Cooling ON/OFF valves | Part number |
|---|-------------|------------|-----------|--|-------------|
| Conveyor supply | LH | х | Х | - | 200-2339-1 |
| | | - | - | Х | 200-2339-2 |
| | | - | - | Х | 200-2339-3 |
| | | Х | Х | - | 200-2339-4 |
| NOTE : In order to have a complete supply from the upright, Gr.1&2 or Gr.3&4 must be selected. | | | | | |
| Air supply piping is located at the cold side of the machine (opposite of conveyor delivery direction). | | | | | |



Installation Requirements

The only requirement for installing the Modular Air Supply Piping is the square (flange) type connection for uprights, overhead, and air manifolds:

| Machine | | | Manifolds connection type | | |
|--------------------|-----------------------|------|---------------------------|-----------------|-------------|
| Part | Number of Sections | Side | Round | Square (Flange) | Part number |
| | | LH | Х | - | 200-2215-1 |
| Linvigita | 6 9 10 10 | RH | Х | - | 200-2215-2 |
| Uprights | 6,8,10,12 | LH | - | Х | 200-2215-3 |
| | | RH | - | Х | 200-2215-4 |
| | 6 | | Х | - | 200-2232-1 |
| | 8 | | Х | - | 200-2232-2 |
| | 10 | n/a | Х | - | 200-2232-3 |
| A in Manifalala | 12 | | Х | - | 200-2232-4 |
| Air Manifolds | 6 | | - | Х | 200-2232-5 |
| | 8 | | - | Х | 200-2232-6 |
| | 10 | | - | Х | 200-2232-7 |
| | 12 | | - | Х | 200-2232-8 |
| | 6 | - | Х | - | 200-1789-5 |
| | 8 | | Х | - | 200-1789-6 |
| | 10 | | Х | - | 200-1789-7 |
| Overhead Manifelds | 12 | m/n | Х | - | 200-1789-8 |
| Overhead Manifolds | 6 | n/a | - | Х | 200-1789-9 |
| | 8 | | - | Х | 200-1789-10 |
| | 10 | | - | Х | 200-1789-11 |
| | 12 | | - | Х | 200-1789-12 |

| Features | Benefits | |
|------------|--|--|
| Modularity | Flexible configuration Readiness for future modifications | |
| Modulanty | Easier Specification | |
| | Meeting of customers' needs | |